
Panasonic G1 Tablets & Docking Stations

Overview

HFD / EMS - August 7, 2014



Laptop Helpline: 713.809.0070


Introduction

Replacing the old ARMOR tablets will be done with Panasonic's G1 toughpad. It's lighter, faster, but uses the same Windows 7 and ImageTrend's FieldBridge software everyone is familiar with. The G1 should boot up and automatically log the user into windows and start FieldBridge for you. When it completes startup, you will be ready to log into FieldBridge. If for any reason, Windows does not log you in automatically, the standard user provided is to login a "**emsuser**" with the password of "**Password1**". Remember, this is the Windows login, not FieldBridge.

Docking the G1



Make sure the dock is fully open, set G1 into dock, press top of dock down until it clicks. Pressing the silver button, centered on the top of the dock will release the tablet.



The buttons for the G1 Toughpad are described as follows:

The "A1" button brings up the "System Config Screen" (*Calibrate the pen*)

The "A2" button activates the bar code scanner on the top edge of the G1

The third and fourth buttons raise and lower the volume as indicated

The fifth button, showing the Windows logo, brings up the Windows program list

The sixth button, as indicated, rotates the screen manually

The Power button is to the far right.

*Reminder: To restart or turn off use the Windows button, **NOT THE POWER BUTTON**



You will also notice on the right side the Driver's License swipe is built-into the tablet itself. It functions as the separate device did before, except it doesn't have to be docked. And finally on the bottom left, in you have to manually charge the G1, the plug is located on the bottom left.